




## Installation Instructions Basement Hoppers



### 1) REMOVE SASH

- A) UNLOCK OPERATING SASH
- B) TILT OPERATING SASH TO FULL OPEN
- C) REMOVE SCREW FROM HINGE ON THE LEFT SIDE OF SASH
- D) REMOVE SASH

### 2) DRILL HOLES

- A) IT WILL BE NECESSARY TO DRILL 4 HOLES FOR EACH JAMB
- B) USING A 1/8" DRILL BIT, DRILL 2 HOLES IN EACH JAMB. ONE NEAR THE HEAD AND ONE NEAR THE SILL.
- C) THE HOLES SHOULD BE DRILLED SO THAT THEY DO NOT INTERFERE WITH THE OPERATION OF THE WINDOW
- D) THE HOLES SHOULD BE DRILLED SO THAT THE SCREWS YOU CHOOSE DO NOT ANCHOR INTO A MORTAR JOINT
- E) THE HOLES SHOULD BE DRILLED SO THAT THE SCREWS YOU CHOOSE ANCHOR INTO YOUR CEMENT BLOCK
- F) IT WILL ALSO BE NECESSARY TO DRILL HOLES INTO THE CEMENT BLOCK THAT LINE UP WITH THE HOLES YOU HAVE DRILLED IN THE FRAME TO ACCOMMODATE A PLASTIC OR LEAD WALL ANCHOR.

### 3) INSTALL WINDOW

- A) AFTER COMPLETING ALL OF THE ABOVE STEPS PLACE THE WINDOW INTO THE HOLE AND INSTALL ANCHOR SCREWS.
- B) INSTALL SASH BY REVERSING THE STEPS IN THE REMOVE SASH SECTION
- C) USING A 100% SILICONE CAULKING SEAL AROUND THE EXTERIOR AND INTERIOR OF THE WINDOW FRAME.

*Service & Reliability You Can Trust*

The information contained herein is provided solely for informational purposes. Seven D Industries, LP disclaims any and all liability associated with the use and/or provision of this information. Any reliance upon the information or advice is at the risk of the party so relying. The information contained herein may be changed from time to time without notification.



Seven D Industries, LP is a DeGol Organization Company [www.7DIndustries.com](http://www.7DIndustries.com) 1-800-807-7006

The manufacturer reserves the right to change or modify products without prior notice.

7D1104M020